



Temperature-dependent Optical Gain and Loss in Continuous-wave Quantum Cascade Lasers between 8.2-10.3 μm

Zhijun Liu and Claire F. Gmachl

Princeton University, Princeton, NJ 08544, USA

Liwei Cheng and Fow-Sen Choa

University of Maryland Baltimore County, Baltimore, MD 21250, USA

Rich Leavitt and Fred J. Towner

Maxion Technologies Inc., Hyattsville, MD 20782, USA

Xiaojun Wang and Jenyu Fan


AdTech Optics, City of Industry, CA 91748, USA

Work supported by DARPA-LPAS, DARPA-EMIL and MIRTHE (NSF-ERC)



Motivation

- Understand QC laser performance
- Improve laser designs
- Limited high-quality gain and loss data


“Vertical transtion”



“Diagonal transtion”



Ridge waveguide



Buried heterostructure

Measurement methods

- 1/L method

$$J_{th} = \frac{\alpha_W + \alpha_M}{g\Gamma} = \frac{\alpha_W}{g\Gamma} - \frac{\ln(R)}{g\Gamma} \frac{1}{L}$$
 - Need several reliable devices
 - Sensitive to threshold measurements especially at low temperature

- Hakki-Paoli method


$$g\Gamma J - \alpha_W = -\frac{1}{L} \left(\ln \left(\frac{V^{1/2} + 1}{V^{1/2} - 1} \right) - \ln \left(\frac{1}{R} \right) \right) = y \quad V = \frac{P_1 + P_2}{2V_i}$$

- Need only one reliable device (short cavity, narrow laser ridge, “clean” spectrum)
- Preferred in this study

B. W. Hakki, et al., J. Appl. Phys. **46**, 1299–1306 (1975)





- Transmission technique and others

D. G. Revin, et al., J. Appl. Phys. **95**, 7584-7587 (2004)







Design and performance of “vertical transition” QC lasers (QCV1) at $\lambda \sim 8.2 \mu\text{m}$



Gain and loss of “vertical transition” QC lasers (QCV1) at $\lambda \sim 8.2 \mu\text{m}$





after T. Matsuoka, et al., *Jpn. J. Appl. Phys.* **29**, 2017 (1990).

M. A. Ordal, et al., *Appl. Opt.* **22**, 1099-1119 (1983)



- Measured gain agrees well with the design
- Measured waveguide loss is much higher than calculated free carrier absorption

Performance of “vertical transition” QC lasers (QCV3) at $\lambda \sim 10.3 \mu\text{m}$








Gain and loss of “vertical transition” QC lasers (QCV3) at $\lambda \sim 10.3 \mu\text{m}$ (Ridge waveguide Vs. BH)




- ▶ Measured waveguide loss is higher than calculated free carrier absorption
- ▶ Side-wall SiN/Au is not the major loss origin




- Resonant absorption accounts for the difference at room temperature
- Large discrepancy remains in low temperature range




Same waveguide with different active region designs



10.3μm, vertical transition (QCV3)








9.6μm, vertical transition (QCV2)



9.8μm, diagonal transition (QCD1)

- Gain agrees well with design for vertical transition lasers, and but is smaller than modeling for diagonal transition laser.
- Higher waveguide loss than calculated free carrier absorption
- Complex temperature-dependence of waveguide loss


Gain and loss for “diagonal transition” QC lasers at $\lambda \sim 9.8$ (QCD1) and 10.1 (QCD2) μm



- Parasitic optical transitions result in smaller gain.
- Much higher loss and unexpected temperature-dependence means other loss origins other than free carrier absorption (resonant absorption, scattering loss, interface state absorption, etc.)



Gain spectrum line-width measurements



- ▶ Longer wavelength lasers have smaller linewidth
- ▶ Diagonal transition lasers have larger, but less temperature-sensitive linewidth



Summary



■ Gain coefficient

- ◆ Agrees well with modeling for vertical transition lasers
- ◆ Smaller than the design for diagonal transition lasers partially due to parasitic carrier leakage

■ Waveguide loss

- ◆ Within range of $12\text{-}25\text{cm}^{-1}$, much higher than free carrier absorption calculation ($3\text{-}12\text{cm}^{-1}$)
- ◆ Intersubband resonant absorption has shown to be an important factor
- ◆ Complicated temperature-dependence (constant, increasing or decreasing) indicates unidentified loss origins in the active core (accidental resonant absorption, interface/defect states, etc.)

■ Acknowledgments

Thanks to Bryan T. Haslam, Grace Silva, and Jayson J. Paulose for their assistance in early parts of the work.